




CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL

MLR 30 · MLR 60 · MLR 90 · MLR 120 · MLR 180 · MLR 270 · MLR 360

MEXICANTORTILLAMACHINE.COM



The total or partial reproduction of this manual
is prohibited by any means, whether printed or electronic;
without the prior, express and written authorization of the author.



CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL

MLR 30 · MLR 60 · MLR 90 · MLR 120 · MLR 180 · MLR 270 · MLR 360

INDEX

GENERAL SAFETY INSTRUCTIONS	4
CAUTION	5
GAS AND ELECTRICAL INSTALLATION	6
MANUAL AND AUTOMATIC IGNITION ELECTRONIC CIRCUIT	7
COMPONENTS	8
ELECTRONIC IGNITION CABINET	9
OPERATING INSTRUCTIONS	10
Manual ignition	10
Automatic ignition	13
CLEANING AND MAINTENANCE	16

GENERAL SAFETY INSTRUCTIONS

WARNING: To reduce the risk of injury, read all instructions properly. Failure to follow the instructions listed below can cause electric shock, fire, serious injuries, mutilation, and/or damage to the equipment.

A. SAFETY IN THE WORK AREA.

- * Keep the work area clean and lit. Crowded or dark areas lead to accidents.
- * Do not operate the equipment without first checking all gas connections with soapy water, to ensure that there are no leaks that could cause an explosion.
- * Keep children, customers, and non-company personnel away from the electrical and mechanical operation area of the equipment.
- * It is recommended to have a minimum space of one meter or three feet around the machine for safety measures and to optimize work.

B. ELECTRICAL SAFETY.

- * Machinery connections must be adapted to the power outlets.
- * Do not use adapters for the switches: since you run the risk of receiving an electric shock.
- * Do not expose the switches and/or electrical connections to rain or humidity. If water enters these elements, there is a risk that they will break down or suffer an electric shock.
- * Use cable in a single piece, if there are joints in the connections these can produce a short circuit.
- * Do not expose cables or electrical connections to heat, oil, sharp edges, or moving parts, as damaged cables can cause electric shock or short circuits.

C. PERSONAL SAFETY

- * Do not operate the equipment if you are tired, or under the influence of alcohol or drugs.
- * Wear appropriate clothing, do not wear loose clothing, necklaces, earrings, or watches, if you have long hair wear a tie to keep it up.
- * Do not climb on the structure of the machine for any reason, falls or injuries may occur.
- * Avoid using headphones, cell phones, or any other equipment that works as a distraction to the operator.
- * Make correct use of personal protective equipment if any maintenance is to be carried out on the machine.
- * If any change is made to the model or component of the equipment, be it electrical, mechanical, or gas related, it must be de-energized, cut off the gas supply, and stop the machine completely to avoid accidents.
- * Keep limbs away from all moving parts.

CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL

CAUTION

The following symbols indicate the safety measures that must be taken before and after starting up the equipment.



HOT HAZARD Some parts of the machine are hot while in operation.



TAKE CARE OF YOUR HANDS Hands should not be inserted while the machine is working.



ELECTRICAL RISK In which you can suffer electric shocks if you do not comply with the electrical safety provisions.



GEAR RISK Keep your hands away from the chains and gears of the machine.



DO NOT COVER THE BARREL'S AIR INTAKE. Keep your hands away from the air inlet of the barrel.

GAS AND ELECTRICAL INSTALLATION


At the outlet of the gas tank, a model 10-080 high-pressure regulator must be installed, with a pressure gauge (0-7 Kg.) to verify the correct supply pressure. The pipe used for the connection is 1" in diameter, either L-type copper or 40-gauge black tubing.

The length of the pipe should not exceed 10 meters, from the outlet of the gas tank.


A union nut must be installed between the stopcock and the low-pressure regulator.

Before the machine's gas input, a low-pressure regulator must be installed.

Verify that the electrical connection is 220v. No short circuits, no loose or bare wires.




MANUAL AND AUTOMATIC IGNITION ELECTRONIC CIRCUIT




CERTIFIED MLR TORTILLA MACHINES OPERATION'S MANUAL

COMPONENTS




ELECTRONIC IGNITION CABINET



ITEM	DESCRIPTION
1	MOTOR'S IGNITION
2	MAIN VALVE'S IGNITION
3	MANUAL PILOT VALVE'S IGNITION
4	CABINET LOCK
5	EMERGENCY STOP
6	SPARK PLUG'S MANUAL IGNITION
7	AUTOMATIC IGNITION
8	AUTO START INDICATOR LIGHT
9	FLAME FAILURE INDICATOR LIGHT

CERTIFIED MLR TORTILLA MACHINES OPERATION'S MANUAL



1

Check that the straps rotate freely



2

Make sure that the wire is tight and not broken



3

Place the cutter on the base, and verify that it is correctly installed and secured



4

Spray grooves and straps with water to remove excess product

MANUAL IGNITION



A

Plug the machine into an electrical outlet and gas outlet



B

Turn the emergency stop button to deactivate it

CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL



C

Open the gas intake valve and press the oven engine start button



D

Turn the pilot valve knob, the indicator will illuminate



E

Press the electronic ignition spark plug button



F

The burners will light up



G

Push the work valve button



H

The oven nozzles will turn on



DO NOT LET THE GRIDDLES HEAT UP FOR TOO LONG WITHOUT PRODUCT. OVERHEATING CAN DAMAGE THE TEFLON.

CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL



I

Turn the pilot valve knob, and indicator and the burners will turn off




J

Check the intensity of the flame in the nozzles, and wait 3 minutes for the griddle to heat up



K

Turn the upper carburetor valve knob to adjust the air intake




L

Turn the lower carburetor valve knob to adjust the gas input



M

Push the work valve off button



N

Turn the emergency stop button to activate it


CERTIFIED MLR TORTILLA MACHINES OPERATION'S MANUAL



Ñ

At the end of the day's production it is important to turn off the WORKING VALVE first, then turn off the oven motors second, once the griddles have cooled

AUTOMATIC ELECTRONIC IGNITION



A

Turn the emergency stop button to energize the machine



B

Press the automatic ignition button for 5 seconds



C

The burners and nozzles will ignite, and after 15 seconds the burners will turn off and the nozzles will remain lighted



D

By pressing the automatic ignition button, the indicator will illuminate for 15 seconds and then turn off



DO NOT LET THE GRIDDLES HEAT UP FOR TOO LONG WITHOUT PRODUCT. OVERHEATING CAN DAMAGE THE TEFLON.

CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL



E

Check flame intensity coming from the nozzles



F

In case of failure, the indicator will illuminate.
Extinguish the flame by pressing
the emergency stop button



5

Add dough to the rollers



6

Raise the clutch lever



7

Adhere dough curtain to the front roller



8

Adjust the tortilla thickness by turning
the adjustment knobs (clockwise to make the
tortilla thinner, and counterclockwise to make it
thicker) Lower the clutch lever when you obtain
the desired thickness

CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL



9

Raise the cutter lever



10

Check the shape of the tortilla



11

Inspect tortilla in the griddle



12

Check the cooking and shape of the finished tortilla



**DO NOT LET THE GRIDDLES HEAT UP FOR TOO LONG WITHOUT PRODUCT.
OVERHEATING CAN DAMAGE THE TEFLON.**

TEFLON COATED METAL BELT

- Heating time of metal belt to start cooking: 2 minutes 50 seconds
- Ideal temperature for cooking on metal belt first level: 330°C (626°F)
- Temperature of metal belts with product in cooking process:
 - First level 295°C (743°F) to 310°C (590°F)
 - Second level 335°C (635°F) to 365°C (689°F)
 - Third level 335°C (635°F) to 345°C (653°F)

Important note 1: Control the temperature increase of the Teflon-coated metal belts without exceeding 370°C (698°F) (when there is no product being cooked, close valves and gas flow).

Important note 2: When keeping burners on without any product being cooked, the temperature of the Teflon-coated metal belts may exceed 500°C (932°F) after 10 minutes, which will cause the Teflon coating to come off.

CLEANING PROCEDURE

WARNING: Cleaning both the rollers and the base must be done with the machine completely stopped to avoid accidents such as crushing.

FRONT ROLLER CLEANING

1. Remove the dough residues from the front roller at total stop with your hands.
2. Turn the machine on again to change the position of the roller, turn off the machine and proceed with cleaning. You must carry out this action as many times as necessary to complete the cleaning of the roller.
3. Clean the cable tie grooves with a plastic bristle brush to prevent the build-up of mass that may break the wire when it dries.
4. Wipe the remaining dough from the top of the roller with a damp cloth.
5. After removing the dough residues from the roller, there will be an excess.
6. Spread a little water after removing the remaining dough to complete the cleaning of the roller.
7. Clean the rollers with a dry cloth after spreading water over them to remove excess moisture.

CLEANING THE REAR ROLLER

1. Clean the rear roller, pour in a little water, and wipe with a cloth to remove any dough residues.
NOTICE: You will need to turn the machine on to change the position of the roller as many times as necessary to clean them completely.
2. After you have cleaned the roller from the front and back, you should wipe the upper part of the stainless steel roller with a damp cloth.
3. Use a damp cloth to clean the base of the bench and remove lumps from the slide with a wire brush.

MAINTENANCE

Clean the machine before and after using it.

The duration of the spare parts will depend on the preventive maintenance and care taken to the machine. The more frequently this maintenance is done, the parts will have a longer life.

CERTIFIED MLR TORTILLA MACHINES OPERATION'S MANUAL

LUBRICATION


The following table shows the parts, the type of lubricant, and the frequency with which the machines and their parts must be lubricated.

PART	LUBRICANT	PERIOD
Chains	BAT 3 Grease	3 times per week
Reducer	SAE 80/90 Mineral Oil	Every 3 months
Packed bearings	BAT 3 Grease	Every 3 days
Griddle hinges	Graphite	Every week
Gears	BAT 3 Grease	Every week
Clutch sprocket	BAT 3 Grease	3 times per week
Slide bronze bushing	BAT 3 Grease	3 times per week



CERTIFIED MLR TORTILLA MACHINES

OPERATION'S MANUAL

The following figures show the schematic location of the parts that require lubrication.



Do not lubricate self-aligning bearings.



It is recommended to change the oil every three months. The used oil must be drained and 400 ml of new SAE 80/90 mineral oil must be added.

The following table shows the type of lubricant to put in all parts of the machine.

LUBRICANT
A) BAT 3 Grease
B) SAE 80/90 mineral oil
C) Graphite





HEADQUARTERS

AV. INDUSTRIAS #3655, ZONA INDUSTRIAL
CP 78395 SAN LUIS POTOSÍ, SLP. MÉXICO



444 127 11 80



444 129 29 79

info@manufacturaslenin.mx

MEXICANTORTILLAMACHINE.COM